

μ CONSOLE FOR PROGRAMMING THE CONVERTERS

LCD μ CONSOLE



A new generation miniaturised LCD console for programming and downloading programming files to the converters and transmitters of the SFERE range.

Programming with the micro-console

It allows:

- the visualisation of the measure and the status of the analog, relay and digital outputs,
- the visualisation and the modification of the programming,
- the teleloading of programming files for duplication to other converters.

DESCRIPTION

• Display:

The graphical display allows:

- displaying the information (value of the measure, unit, status of the outputs) on 4 lines,
- using either mode portrait/landscape to display these data in case of horizontal mounting of the converter,
- visualising curves or histograms.


- The rear-lighting of the display allows using the console in little lit areas.
- A 4-key keyboard allows access:
 - to the reading or modification of the programming,
 - to the converter specific functions.

- Material: self-extinguishing black UL 94V0 PA66
- IP 40 case
- CE marking

DIMENSIONS

- Dimensions: (HxLxD) 80 x 26.5 x 20

Indication of the status of the converter relays (if option relays)



Display of the measure (height: 5.0 mm)

Display of the measure unit (height: 3.5 mm)

Display of the value of the analog output, or the product marking name (eg.: TANK)

Indicates the activity (measurement) of the converter

Indicates the communications on the RS485

Société Française d'Etudes et de Réalisations Electroniques - SFERE

Route de Brindas - Parc d'Activité d'Arbora - N°2
69510 SOUCIEU EN JARREST - FRANCE

Tél. : 04 78 16 04 04 Fax : 04 78 16 04 05
Tel. Intern. : 33 4 78 16 04 04 Fax Intern. : 33 4 78 16 04 05
e-mail : info@sfere-net.com http : //www.sfere-net.com

